
Product Details









- 1 Easily screwing off the sealed ABS top cover, filling liquid conveniently.
- 2 Easily taking off the transparent PC bottle to wash.
- 3 Infrared sensor system activated in 0.5 seconds to dispense liquid automatically.
- 4 With a waterproof stand can prevent water effectively.
- 5 Working by 4pcs alkaline batteries which can last for several months.



Operation Instruction

- Place batteries according to the polarity (+/_) marked on the battery compartment.ZYX-05E working by 4pcs "AA" battries,ZYX-025E working by 4pcs "AAA" batteries.
- 2. Screw off the top cover, fill in the soap container with liquid soap to a suited level, the liquid soap should not contain any solid particles.
- 3. Press the On/Off button until the indicator's light turn blue. Then it is in working status. Put your hands under the soap nozzle, the indicator light turns blue, then it can dispense soap liquid in 1 second. Sensor distance is within 8cm.
- 4. When you want to get more soap ,press the ON/OFF button shortly, the indicator light flashes blue in 2 times, then it can dispense soap in 2 seconds. If you want to get most, press the ON/OFF button shortly again, the indicator light flashes blue in 3 times ,then it can dispense soap in 2.5 seconds. (There are 3 steps you can preset.)
- 5. Under normal operation, press the ON/OFF button for 3 seconds until the indicator light turns off. Then the unit is in closed status.

Attention

- 1.When you use the new one, please activate sensor about 3-10 times firstly after you fill in liquid, to make sure that the air in the tube can be pushed out completely.
- When the liquid is lower, please add some to make sure it can dispense liquid normally.
- 3.Don't impact the product severely, it may be damaged.
- 4.Remove batteries when the unit is not used for a long time. Always remove exhausted batteries and dispose of safely.
- 5.Don 't lean the product to avoid the liquid flows out.
- 6. This product is only suitable for indoor use. Avoid direct sunlight to the infrared panel.
- 7.Do not wash or immerse the unit, it may be cleaned with a damp cloth.

